

Collector, Wampserver and DB Monitor Installation guide

Purpose:

Guide for NEWSTEO Collector installation:

- For a Newsteo data hosting
 - or
- When the hosting is done on the server of the customer
- With a DB Monitor interface


Technical Assistance:

For any question, remark or suggestion concerning this product, please contact your retailer.



1	OPERATION OF A FACILITY WITH NEWSTEO COLLECTOR	
2	IMPORTANT REMARKS BEFORE THE INSTALLATION	4
	2.1 IF YOU HAVE CHOSEN TO USE THE NEWSTEO DATA HOSTING2.2 IF YOU ARE HOSTING YOUR DATA BY YOUR OWN	
3	CREATE YOUR OWN DATABASE	4
	 3.1 STOP MYSQL SERVICE (IF YOU WERE USING THE RF MONITOR SOFTWARE) 3.2 WAMPSERVER INSTALLATION 3.2.1 Install Wampserver from the website 3.2.2 Create your Database 3.2.3 Mail Server configuration for collectors 3.2.4 Plannification of the tasks WINDOWS 3.2.4.1 Test the presence of the COL 3.2.4.2 Automatic generation of reports 3.2.4.3 Backup of the database 	
4	START YOUR COL AND YOUR LOGGERS ON THE DEFAULT DATABASE PROVIDED BY NEWSTEO	19
	 4.1 CONNECT THE DEFAULT DATABASE PROVIDED BY NEWSTEO 4.2 START THE COL 4.3 START THE LOGGERS 	20
5	CONFIGURE YOUR PRODUCTS	21
	 5.1 CONFIGURE YOUR LOGGERS	22 23 23 23 24 24 24 24 24 24 25
6	INSTALL DB MONITOR AND CONNECT DB MONITOR TO YOUR OWN DATABASE	
	 6.1 INSTALL DB MONITOR (NEWSTEO KIT) 6.2 CONNECT DB MONITOR TO YOUR OWN DATABASE	
7	CONNECT THE COL TO YOUR OWN DATABASE	30
8	ANNEXE – YOU CAN'T REMEMBER YOU IP ADDRESS	30

1 Operation of a facility with Newsteo collector



2 Important remarks before the installation

2.1 If you have chosen to use the Newsteo Data hosting

You don't need to install wampserver and to create your own database. You are only concerned by the paragraphs **4 Start your COL and your loggers on the default database provided by Newsteo** and the paragraph **5 Configure your products**

2.2 If you are hosting your data by your own

- You must have a fixed IP address
- Ensure that the Windows firewall will not block the HTTP port (default 80) and the SQL port (3306 by default).
- It is important to be **administrator** of the machine to install WampServer
- The installation must be performed by the network administrator
- **IF BEFORE YOU WERE USING THE RF MONITOR GOLD SOFTWARE**, it is necessary to stop the MySQL service
- We recommend the use of Google Chrome
- Not fully compatible with Internet Explorer

Then follow the installation with the next paragraph.

3 Create your own Database

3.1 Stop MySQL service (If you were using the RF Monitor software)

 Start the service manager : services.msc Enter services.msc in the Starting menu Press [Entrer] 	Programs (1) Services.msc See more results Services.msc X Shut down Shut down Shut down
- Right click on MySQL then click Properties	Multimedia Class Enables relax Museume Restaure R
 Change the Startup type : Change « Automatic » to « Deactivated » Click on Stop Click on OK 	Propriétés de MySQL (Ordinateur local) EX Général Corresson Récupération Dépendances Nem du service : MySQL Nem complet :: MySQL Description :: Image: Status and Status a
 The MySQL service state is now « Deactivated » Close Management Services window 	Moteur de filtrage Le moteur d Dém Automatique MySQL Dém Désactivé Netlogon Maintient u Manuel

3.2 Wampserver installation

3.2.1 Install Wampserver from the website

Unzip the file: Newsteo_Collector_Gold_Server_KIT_Vx.xx.x_yyyymmdd.zip Open the Directory: Newsteo_Gold_Server Double Click on Newsteo_Gold_Server.bat to start the installation Click Yes	
Open the Directory: Nom Modifié le Newsteo_Gold_Server Appli 14/11/2016 15: Double Click on Newsteo_Gold_Server.bat 14/11/2016 15:	
Double Click on Newsteo_Gold_Server.bat to start the installation	Type Taille
Click Yes	28 Fichier de comma 1 Ko
	A standard and a
	Newstee Gold Server V11 Of of -WM/R, S700-0NG3X-011-0101 pdf from www Fee Download
Select the language to perform the installation	
At starting, the user guide of the collector is automatically opened You can also get the user guide by clicking on Help	192.168.0.80 Port 80
The IP address of your computer is automatically detected.	Create
First create the Server by selecting Server Creation	C0L000001 C0L000001 Pessword
Click Create	Create
wait	
Click OK	Application information
quick launch icon" and "Create a desktop icon"	oft Visual C++ 2008 Redistributable Setup
Accept the agreement when needed	rd will guide you through the installation process.
Click Next	Next > Cancel



Select I have read and accept the license terms	Microsoft Visual C++ 2008 Redistributable Setup
	License Terms
Click Install Click Finish	Re sure to carefully read and understand all the rights and restrictions described in the Learnes terms. You must accept the locense terms before you can install the software. MICROSOFT SOFTWARE LICENSE TERMS MICROSOFT VISUAL C+ 2008 Redistributable Setup MICROSOFT Visual C+- 2008 Redistributable Setup MICROSOFT Visual C+- 2008 Redistributable Setup
	Setup Complete
	Hicrosoft Visual C++ 2008 Redistributable has been successfully installed. It is highly recommended that you download and install the latest service packs and sourthy updates for this product. For more information, visit the following Web site: Product Support Center
	Find
Click OK	Application information 23 To install WAMP, choose default parameters.
Wait	
Click Next	Setup - WampServer 2 WampServer WampServer Powered by Alter Way The French Open Source Service Provider http://www.alterway.fr Apache : 2.2.21 dySQL : 5.5.30 Priffyiodati : 3.4.310.1 SqlBuddy : 1.3.3 XDebug : 2.1.2 Kancel
Select I accept this agreement	Setup - WampServer 2
Click Next	License Agreement Please read the following important information before continuing. Please read the following License Agreement. You must accept the terms of this agreement before continuing with the installation. Please read the following License Agreement. You must accept the terms of this agreement before continuing with the installation. "** WangServer "by "Creator "Benatine" / Upg de Readmang ORU CB/BEA, PRILC LICENSE Version 2, June 1991 Copyright (C) 1989, 1991 reso Shrave Foundation, Inc. @1 accept the agreement I do not accept the agreement Lide the agreement
Click Next	Select Destination Location
	Select Destination Location Where should WampServer 2 be installed? Image: Setup will install WampServer 2 into the following folder. To continue, dick Next. If you would like to select a different folder, click Browse. Image: WampServer 2 into the following folder. To continue, dick Next. If you would like to select a different folder, click Browse. Image: WampServer 2 into the following folder. To continue, dick Next. If you would like to select a different folder, click Browse. Image: WampServer 2 into the following folder. At least 216,0 MB of free disk space is required. Cancel

Select Create a quick launch icon	Setup - WampServer 2 Select Additional Tasks Which additional tasks should be performed?
Select Create a desktop icon	Select the additional tasks you would like Setup to perform while installing WampServer 2, then click Next.
Click Next	Additional icons: Create a Quidk Launch icon Create a Desktop icon
	< Back Next >> Cancel
Click Install	Setup - WampServer 2 Ready to Install
	Ready to Install Setup is now ready to begin installing WampServer 2 on your computer. Click Install to continue with the installation, or click Back if you want to review or
	change any settings. Destination location: c; livano
	Additional tasks: Additional icons:
	Create a Quick Launch icon Create a Desktop icon
Wait	<box cancel<="" drotal="" th=""></box>
Choose your default browser	Please choose your default browser. If you are not sure, just click Open :
	Organize • New Folder Image: Second Mindows • • • • • • • • • • • • • • • • • • •
If you are not sure, just click Open	★ Favorites Name Date modified Type ■ Destrop ■ addins 14/07/2005/09/732 File foll ■ Destrop ▲ AppCompat 14/07/2005/07/72 File foll
	Recent Places AppPatch 12/04/2011 11:16 File fol assembly 21/11/2010 04:57 File fol
	↓ Lêtravies ■ Boct 14/07/2009 07:32 File fol ▶ Documents ■ Beanding 14/07/2009 07:32 File fol ↓ Music ▲ Currers 14/07/2009 07:32 File fol
	➡ Pictures ➡ delug 0.4/06/2023 1660 File fol ➡ Videos ➡ diagnostics 1.4/07/2020 07:32 File fol ➡ Diptatiocker 1.2/04/2013 11:16 File fol
	Computer Downloaded Program Files 14/07/2008 07:32 File fol
	File name rest files (".ext) • Copen • Cancel
Click Next	Setup - WampServer 2
	PHP mail parameters
	Please specify the SMTP server and the adresse mail to be used by PHP when using the function mail(). If you are not sure, just leave the default values. SMTP:
	localhost
	Emal: j=mai@yourdomain
	Next >
Click Finish	Setup - WampServer 2
	Completing the WampServer 2 Setup Wizard
	WampServer Setup bas finished installing WampServer 2 on your computer. The application may be launched by selecting the installed cons. Powered by Control of an observed by
	Alter Way Click Finish to exit Setup. The French I Launch WampServer 2 now
	Service Provider http://www.alterway.fr
	MySQL : 5.5.20 PHP : 5.3.10 PHPMvAdmin : 3.4.10.1
	SqlBuddy : 1.3.3 XDebug : 2.1.2
Wait Wait Wait	<8adk Finab
Click OK	Application information
	Server creation Success. To be complete, please restart your PC.
	ОК



Click [X] to close the windows	Newsteo Gold Server V3.1	
	English	Help
Restart your computer	C 1.Server creation and scripts Address 192.168.0.80 Port 80	
	Current state : Server installation success.	
		1odify
	C.Database creation	
	User COL000001 Password Current state :	
		Create

3.2.2 Create your Database

Restart the installation kit that you previously downloaded from the Newsteo Website as indicated at the beginning of: 3.2.1 Install Wampserver from the website	
Click Yes	
	Newstee Gold Sarver V3.1 Development of the sarver Similar Sarver Sarve
Newsteo recommand you to archive your Wamp server. Click Yes	Information Newsteo vour recommande d'archiver votre serveur wamp. Voulez-vous continuer?
Wait Wait Wait	Oui Non
Accept the update of your scripts Click Yes Wait Wait Wait	Information weather a jour les scripts. ¹ Voulet-vour emettre à jour les scripts. ² Peur votre information, un fichier scripts, dats aip sens crite automatiguement dans la répartore wamp ¹ nom. <u>Cour</u> Hon
Select the language to perform the installation At starting, the user guide of the collector is automatically opened You can also get the user guide by clicking on Help	Newsteo Gold Server V3.1 Languages T. Server creation and scripts
Select Database creation Enter a Name and a Password Geharacters mandatory Remember also the IP Adress Click Create	Address [192.168.0.80 Pert 80 Current state : Installation du serveur réussie. Create Create Create Current state : Create Create Create Create
WaitWait Wait	Imp//192.188.0.80/create_server4.php?unxCO(0000018.ctear_peed=cC0)
Once the database is created, you get the message : Creation of Database COLXXXXXX OK in the first tab of your browser	Terroris
Click [X] to close the windows	Ancester Gold Server V11 Indexempling Ange Indexempling Ange Indexempling Ange Indexempling Indexempli



3.2.3 Mail Server configuration for collectors

Select Mail Server Configuration for c	ollectors	© 3.Mail server configuration for collectors
Please contact your network administ parameters Enter the name of your database in th	-	SMTP server smlp.gmail.com SMTP Port S87 Securization tis Login user@gmail.com Password **** Sender user
Verify that the serial number of your (necessary in the email configuration V Enter also the recipient email address For several recipient, separate the em	Vindow for this COL.	Emails addresses Database COL000001 E COL000001 E COL000001 Cdrevrateolggmail.com,test@news
If you have several collectors, click on enter the recipient email addresses fo Click on Test mails		Emails addresses Database COL000001 tdnewsteo@gmail.com,test@n + B COL00002 tdnawsteo@gmail.com
Click OK		Application information
Verify your emails box		Please check your emails box OK
Click on Configure		+
You can verify that the configuration file has been created in : C:/wamp/www/COLxxxxxx/col_config_emails.json		Construction of the second secon
	Col_config_emails.json ⊠	Paramétrage Macro Exécution Compléments Documents ? R R I I I I I I I I I I I I I I I I I I

3.2.4 Plannification of the tasks WINDOWS

Click WINDOWS icon	Programs (1)	
Enter the command: Task Scheduler	Task Scheduler	
Press Enter	See more results Task Scheduler × Shut down	

3.2.4.1 Test the presence of the COL

Select Task Scheduler Library	() Task Scheduler
	File Action View Help
Right click in the main screen	Image: A status Triggers Next Run Image: A status Triggers Next Run
Click Create New Task	Right click Create Basic Task Create New Task Import Task Refresh
In the General Tab, enter the name of the task:	() Create Task
_NEWSTEO_COL_PRESENCE	General (riggers) Actions Conditions Settings
Select the options as on the opposite screen shot	Name: NEWSTEO_COL_PRESENCE Location: \ Author: WIN-A02F595TEOV\QA Description: \ Security options \ When running the task, use the following user account:
	WIN-A02FS95TEOV\QA Change User or Group Run only when user is logged on Run whether user is logged on or not Do not store password. The task will only have access to local computer resources. Run with highest privileges
Click the Tab Triggers	Hidden Configure for: Windows Vista [™] , Windows Server [™] 2008 V
	OK Cancel
In the Triggers Tab, click New	Create Task General Trigger Actions Conditions Settings When you create a task, you can specify the conditions that will trigger the task. Trigger Details Edit Delete OK Cancel
Select the options as on the opposite screen shot	New Trigger Begin the task: One time Start: 14/10/2013 1 1 1 0 0 0 0 0 0 0 1 0 0
Click OK	(V)Enabled
	Cancel
The details of the triggers appear now in the window Triggers	Create Task General (1999) Actions: Conditions Settings When you create a task, you can specify the conditions that will trigger the task. Trigger Details Daily At 00:00 every day - After triggered, repeat every 10 minutes for Enabled New Edit Delete
Click the Tab Actions	
Click the Tab Actions	OK Cancel



In the Actions Tab, click New	🕒 Create Task
	General Triggers Actions Conditions Settings
	When you create a task, you must specify the action that will occur when your task starts.
	Action Details
	Edit Delete
	OK Cancel
Complete the window as on the opposite screen shot	New Action
	You must specify what action this task will perform.
	Action: Start a program
	Settings
	Program/script:
	C:\wamp\bin\php\php5.3.10\php.exe Browse
	Add arguments (optional):
	Start in (optional):
	C:\wamp\www\col_alarm_presence_01_launch.php
	OK Cancel
The details to start the program appear now in the	() Create Task
window Actions	General Triggers Actions Conditions Settings
	When you create a task, you must specify the action that will occur when your task starts.
	Action Details
	Start a program C:\wamp\bin\php\php5.3.10\php.exe C:\wamp\www\col_alarm_presence
	×(
	New Edit Delete
Click the Tab Conditions	OK Cancel
You shouldn't have to modify anything in this window.	() Create Task
Just verify that you have the same thing as on the	General Triggers Actions Conditions Settings
opposite screen shot.	Specify the conditions that, along with the trigger, determine whether the task should run. The task will not run if any condition specified here is not true.
	Idle Start the task only if the computer is idle for: 10 minutes
	Wait for idle for: 1 hour +
	Restart if the idle state resumes Power
	Start the task only if the computer is on AC power
	Stop if the computer switches to battery power Wake the computer to run this task
Click the Tab Settings	Network Start only if the following network connection is available:
	Any connection
	OK Cancel
	on concer

Complete the window as on the opposite screen shot	Create Task
	General Triggers Actions Conditions Cettings
	Specify additional settings that affect the behavior of the task.
	Allow task to be run on demand Run task as soon as possible after a scheduled start is missed
Click OK	I minute -
	Attempt to restart up to: 3 times
	Stop the task if it runs longer than:
	If the running task does not end when requested, force it to stop
	If the task is not scheduled to run again, delete it after: 30 days -
	If the task is already running, then the following rule applies:
	Stop the existing instance
	OK Cancel
The Task _NEWSTEO_COL_PRESENCE appears now in the	
window Task scheduler.	File Action View Help
	Task Scheduler (Local) Name Status Triggers
	Task Scheduler Library

3.2.4.2 Automatic generation of reports

Select Task Scheduler Library	Task Scheduler				
Right click in the main screen	File Action View Help				
Click Create New Task	Task Scheduler (Local) Name Status Triggers NewSTEO_COL_PRESENCE Ready At 00:00				
	Create Basic Task Create New Task Import Task Refresh				
In the General Tab, enter the name of the task:	() Create Task				
_WEBMONITOR_Automatic_Generation_of_reports	General Tinggers Actions Conditions Settings Name: WEBMONITOR_Automatic_generation_of_reports				
Select the options as on the opposite screen shot	Location: VIN-A02F395TEOV\QA Description: Security options When running the task, use the following user account: WIN-A02F395TEOV\QA Change User or Group Run whether user is logged on Run whether user is logged on or not				
Click the Tab Triggers	Configure for: Windows Vista [™] , Windows Server [™] 2008 OK Cancel				
In the Triggers Tab, click New	© Create Task General Trigger Actions Conditions Settings When you create a task, you can specify the conditions that will trigger the task. Trigger Details Status Edit Delete OK Cancel				



Select the options as on the opposite screen shot	New Trigger
	Begin the task: On a schedule
	Settings
	() Daily
	Weekly Recur every: 1 days
	Monthly
	Advanced settings
	Delay task for up to (random delay): 1 hour
Click OK	Repeat task every: 1 hour for a duration of: 1 day for a duration of:
	Stop task if it runs longer than:
	Expire 14/10/2014 v 16:28:30 Synchronize across time zones
	(V) Enabled
	OK Cancel
The details of the triggers appear now in the window	© Create Task
Triggers -	When you create a task, you can specify the conditions that will trigger the task.
	Trigger Details Status
	Dativ At 00:00 every day Enabled
	New Edit Delete
	OK Cancel
Click the Tab Actions	
	🖲 Create Task
In the Actions Tab, click New	General Triggers Actions Conditions Settings
	When you create a task, you must specify the action that will occur when your task starts.
	Action Details
	New) Edit Delete
	OK Cancel
Complete the window as on the opposite screen shot	New Action
P	You must specify what action this task will perform.
	Action: Start a program
	Settings
	Program/script: C:\wamp\bin\php\php5.3.10\php.exe
	Add arguments (optional):
	Start in (optional):
	C:\wamp\www\col_generation_auto_rapports_launch.php
	OK Cancel
The details to start the program appear now in the	() Create Task
window Actions 🔶	General Triggers Actions Conditions Settings
	When you create a task, you must specify the action that will occur when your task starts.
	Action Details Start a program C:\wamp\bin\php\php5.3.10\php.exe C:\wamp\www\col_generation_aut
	start a program C:(wamp.bin:(pnp):pnp):J:U(pnp.exe C:(wamp/www/col_generation_auto
	New Edit Delete
Click the Tab Caralities	OK Cancel
Click the Tab Conditions	


You shouldn't have to modify anything in this window.	Create Task		
Just verify that you have the same thing as on the	General Triggers Actions Conditions Settings		
opposite screen shot.	Specify the conditions that, along with the trigger, determine whether the task should run. The task will not run if any condition specified here is not true.		
	Idle Start the task only if the computer is idle for: 10 minutes		
	Wait for idle fon: 1 hour + V Stop if the computer ceases to be idle Restart if the idle state resumes		
	Power Vestigned Start the task only if the computer is on AC power Vestigned Stop if the computer switches to battery power Vestigned Wake the computer to run this task		
Click the Tab Settings	Network		
	OK Cancel		
You shouldn't have to modify anything in this window.	Create Task		
Just verify that you have the same thing as on the opposite screen shot.	General Triggers Actions Conditions Settings Specify additional settings that affect the behavior of the task. Image: Specify additional settings Image: Specify additing Image: Specify additional setting<		
	Allow task to be run on demand		
	Run task as soon as possible after a scheduled start is missed If the task fails, restart every:		
Click OK	Attempt to restart up to: 3 times		
	Stop the task if it runs longer than: 3 days -		
	If the running task does not end when requested, force it to stop If the task is not scheduled to run again, delete it after:		
	If the task is already running, then the following rule applies:		
	Do not start a new instance 🔹		
	OK Cancel		
The Task	O Task Scheduler		
_WEBMONITOR_Automatic_Generation_of_reports	File Action View Help		
appears now in the window Task scheduler .	③ Task Scheduler (Local) Name Status ◎ _NEWSTEO_COL_PRESENCE Ready ● _WEBMONITOR_Automatic_generation_of_reports Ready		

3.2.4.3 Backup of the database

Select Task Scheduler Library	() Task Scheduler
Right click in the main screen	File Action View Help
Click Create New Task	Task Scheduler (Local) Name NewSTEO_COL_PRESENCE WEBMONITOR_Automatic_generation_of_reports
	Create Basic Task Create New Task
	Import Task Refresh



In the General Tab, enter the name of the task:	🕒 Create Task
_NEWSTEO_BACKUP	General Triggers Actions Conditions Settings
_NEWSIEO_DACKOP	Name:NEWSTEO_BACKUP
	Location: \
Select the options as on the opposite screen shot	Author: WIN-A02FS95TEOV\QA
	Description:
	Security options
	Security options When running the task, use the following user account:
	WIN-A02FS95TEOV\QA Change User or Group
	Run only when user is logged on
	Run whether user is logged on or not
	Do not store password. The task will only have access to local computer resources.
	Run with highest privileges
Click the Tab Triggers	☐ Hidden Configure for: Windows Vista™, Windows Server™ 2008
	OK Cancel
]]]
In the Triggers Tab, click New	() Create Task
	General Triggers Actions Conditions Settings
	When you create a task, you can specify the conditions that will trigger the task.
	Trigger Details Status
	New Edit Delete
	OK Cancel
Select the options as on the opposite screen shot	New Trigger
	Begin the task: On a schedule 🗸
	Settings
	One time Start: 15/10/2013 ■▼ (01:00:00) ★ Synchronize across time zones
	Daily
	Weekly Recur every: 1 days
	Monthly
	Advanced settings
	Delay task for up to (random delay): 1 hour
Click OK	Thour for a duration of: 1 day
	Stop all running tasks at end of repetition duration
	Stop task if it runs longer than:
	Expire: 15/10/2014 T:11:17:40 Synchronize across time zones
	Enabled
	OK Cancel
The details of the triggers appear now in the window	(B) Create Task
The details of the triggers appear now in the window	General Triggers Actions Conditions Settings
Triggers ->	
	When you create a task, you can specify the conditions that will trigger the task.
	Trigger Details Status
	Daily At 01:00 every day Enabled
	New Edit Delete
Click the Tab Actions	OK Cancel
In the Actions Tab, click New	© Create Task
	General Triggers Actions Conditions Settings
	When you create a task, you must specify the action that will occur when your task starts.
	Action Details
	New) Edit Delete
	OK Cancel





The _Newsteo_backup.bat appears now in the directory (C:)_NEWSTEO_BACKUP	Computer > Local Disk (C:) > _NEWSTEO_BACKUP				
	Organize Include in library Share with Burn New folde				
	Image: Computer Name Image: Local Disk (C:) Image: Local Disk (C:) Image: Local Disk (C:) Image: Local Disk				
Complete the window as on the opposite screen shot	New Action				
	You must specify what action this task will perform. Action: Start a program Settings Program/script: C:\ NEWSTEO_BACKUP_Newsteo_backup.bat Add arguments (optional): Start in (optional): OK				
The details to start the program appear now in the Actions window \rightarrow Click the Tab Conditions	Create Task General Triggers Action Condition Settings When you create a task, you must specify the action that will occur when your task starts. Action Details Start a program Ci_NEWSTEO_BACKUP_Newsteo_backup.bat ·· T New Edit Delete OK Cancel				
You shouldn't have to modify anything in this window. Just verify that you have the same thing as on the opposite screen shot.	Create Task Create Task Create Task Condition Cettings Specify the conditions that, along with the trigger, determine whether the task should run. The task will not run if any condition specified here is not true. Idle Start the task only if the computer is idle for: Name Restart if the idle state resumes Power Start the task only if the computer is on AC power Start the task only if the computer is on AC power Make the computer or run this task Network Start of the following network connection is available:				
Click the Tab Settings	Any connection				
	OK Cancel				
Complete the window as on the opposite screen shot	Create Task Ceneral Triggers Actions Conditions Cetting Specify additional settings that affect the behavior of the task. Allow task to be run on demand Run task as soon as possible after a scheduled start is missed If the task fails, restart every: Attempt to restart up to: Stop the task if it runs longer than: Define the task is not scheduled to run again, delete it after: H the task is already running, then the following rule applies: Run a new instance in paralle Cott				
The Task _NEWSTEO_BACKUP appears now in the Task	C Task Scheduler				
scheduler window.	File Action View Help				
Close the window Task Scheduler	Vane Status Triggers Name Status Triggers NeWSTEO_BACKUP Ready At0000 ever NeWSTEO_COL_PRESENCE Ready At0000 ever NeWSTEO_COL_PRESENCE Ready At0000 ever NeWSTEO_COL_PRESENCE Ready At0000 ever Second				

4 Start your COL and your loggers on the default database provided by Newsteo

4.1 Connect the default Database provided by NEWSTEO

You will configure the connection to a test database provided by Newsteo, allowing you to validate the correct operation of your installation.

Return your collector to find the technical information required.

At the back of your COL, you will find the technical information required. • the Database Name • the Login • the Password	COL22-3 Configuration RF Monitor & DB Monitor Höte: (b.newsteo-webmonitor.com) Höte: (b.newsteo-webmonitor.com) Hort: (data) Nom d'utilisateur: (XXXX) Nom d'utilisateur: (YYYYYY) Nom d'utilisateur: (YYYYYY) Nom d'utilisateur: (YYYYYY) Nom : (YYYYYY) Vacation (data) Nom d'utilisateur: (YYYYYY) Nom : (YYYYYY) Nom d'utilisateur: (XXXXX) Mot de passe: (YYYYY)
Open your Internet browser Enter <u>www.newsteo-webmonitor.com</u>	 ← → C ▲ https://app.newsteo-webmonitor.c ♣ Q ♥ № ☆ : Applications ⑦ Transmission de donn ⑧ Newsteo Portal M Gmail »
Do not forget to select the language Enter the Database Name and the Login	
Enter the Password	Database name :
Click LOG IN	XXXXXX Password Remember me Log IN Legal notice V5.0.20.0 Copyright by Newsteo S.A.S. 2012 - 2016
In Dashboard	Alers Messages Help
You get the message Loading data error	 in Dashboard in Alert Log in A
Click on Paramètres Click on Interface Select the language	Alerts Messages Help Interface settings Select language :



4.2 Start the COL

Start first webmonitor on the default database provided by NEWSTEO (see paragraph: 4)

Description: RADIO: Indicator light for the Radio reception SERVER: Indicator light for the Ethernet communication POWER: Indicator light for the Power supply Collector connection: First connect the battery Screw the antenna on RADIO ANT Plug the Ethernet cable on ETHERNET Plug the power supply on POWER Wait for 3 sound beep from your COL	RADIO SERVER POWER ETHERNET ETHERNET ETHERNET ETHERNET ETHERNET ETHERNET
Click on Settings Click on Devices Select the Line of your COL Click Reload	Definition for definition and exact the set (2.1.2.1.1 definition for set (2.1.2.1.2.1 definition for set (2.1.2.1.2.1.2.1 definition for set (2.1.2.1.2.1.2.1.2.1.2.1.2.1.2.1.2.1.2.1
Press ACK Button on the back of your COL	Indexeter - Nexter + Indexeter - Nexter + Image: State - Nexter + Image: State - Nexter + Image: State - Nexter +
After the sound BEEP, refresh the internet page	Image: State State State State State Sta
The Line of your COL reappears	Image: Some Analysis of Control of Con
The COL is now correctly detected	▲ Articia Image: Social Analysis December 2019 Difference Difference <t< th=""></t<>

4.3 <u>Start the loggers</u>

For each logger you have, repeat the following process:

Once your COL is correctly detected (see paragraph 4.2 Start the COL), pass the magnet on each logger to see the loggers appear in the list	
After the sound BEEP, refresh the internet page (click F5)	Image: Second
The logger appears in the list	Image: Section Image:

5 Configure your products

To modify the configuration, for each product, you will		Alerts Me	sages 😐 Help				
have to:	脅 Dashboard	Display 100 - records	i per page				
	Alert Log	Config.	Serial Number	Description	ID	Logger type	RF settings
	Reports		COL00005C		92	C0L22-2	Channel 1
	Settings		COLODOSC	C0L22-2_00005C	92	00122-2	Channel 1
	Devices Firmware update	• •	L060014E5	L0G22-2_0014E5	5349	L0622-2	Channel 1
	Interface						
	E-mail server PDF report						
	Loggers alerts						
	Loggers group						
Click on Settings		de RELOAD	BERNATE	COMMAND LIST			
Click on Devices	Dnewsteo	Alerts Me	isages PHelp				
Click on the Configuration icon of the logger or of the	👘 Dashboard	Display 100 - record	per page				
COL	Alert Log	Config.	Serial Number	Description	D	Logger type	RF settings
	Reports	•	COLOODOSC	COL22-2_00005C	92	COL22-2	😤 Channel 1
	Devices Firmware update	•	L0G0014E5	LDG22-2_0014E5	5349	L0622-2	😤 Channel 1
First, Configure your loggers	Interface						
First, Configure your loggers	E-mail server PDF report						
	Loggers alerts						
	Loggers group						
		reload 👪 H	BERNATE	COMMAND LIST			



5.1 **Configure your loggers**

Each time you save a new configuration for a logger, do not forget to :

- Pass the magnet on your logger If you are not able to reach your logger, wait for the sound BEEP
- After the sound BEEP, refresh the internet page (click F5) •

Configure the Identification 5.1.1

For each logger that you have:	Logger LOG0014ES settings Device identification RF Settings Time	* Period Thresholds
	Serial Number:	LOG0014E5
Click on Devices identification	Device ID:	5149
➔ You can change the device ID (ex: 1, 2)	Device Description:	LD622-2,0014E5
➔ You can change the Devices description (ex: warehouse)	Product type:	[10622-2
Click on Save	Firmware version:	2.3.6
		SAVE CANCEL

Configure the channel – RF settings 5.1.2

You powered your COL and your logger(s) by default on the channel 1 which is the channel for startup. You must now change the channel: A Control operated by JZ 18/09/43

- Use the securization of the channel if this option is available for all your loggers (available for all LOG - also available for all LGR which have a "Calibration usine")
- You must modify the channel of all your loggers before modifying the channel of • your COL
- The loggers and the COL must have the same channel to communicate •

For each logger that you have:	Logger LOG000CBA settings X					
	Device identification RF Settings Time Period Thresholds					
Click on RF Settings	RF channel					
 → Select a working channel different from the channel 1 → Activate the security (if avaivalable for all your loggers) – by default the securization proposed is the serial number of your COL 	Localization: Boot channel: Working channel:	On Burger 668 1497				
	Power consumption					
Note:	Output power:	100km 30mA ψ Default is +000km				
Chanel Security	Sensitivity:	🕑 High 🔾 Low Default is High				
	Channel securization					
	Security:	COLODOSC				
Click on Save		SAVE CANCEL				
Remark: As for each command, after the save, pass the magnet on your	🔶 🔁 https://www.newstea-webmanitar.com/VEM4/instings/laggers 26 Les plus visités 🚼 Debuter avec Feefox 🏖 http://twesitet.google d Dest	송 = 전 85 - Mynambdal Acom Agent - An. 🎗 System Dabbaard - N 🕽 Transmission de dann. 🔛 PRONOTI, Lagiciel de 🗃 Hour- veel d'essemb				
logger to send the command. After that, the line of the logger still indicate that a command is waiting.	Destoard Destoard Destoard	Hep				
It's normal, because the COL can not communicate anymore with the logger.	A Alerting Comp Setal Nam Comp Setal N					
Click Settings	Finners spatial starker Load some bold report	DA LINDI GA 1 LINDI 3 Convert 1 LINDI 4 2.1.6				
Click Devices Select the Line of your LOG Click Reload	politica interesti politica inte	B GOOD TOY B GOODERAL				

1

The line of the logger disappear


<u>Warning</u>: To be able to continue to communicate and to configure the loggers, you must set all the loggers on the same channel. For this, you must also configure the COL on the same channel (5.2.2 Configure the channel – RF settings)

🚔 Dashboard	Distan	records pe					
Alert Log		Config.	Sertal Number	Description	D	Logger type	RF settings
Reports							
9 Settings			COL000084	C0122-2_000084	152	COL22-2	😴 Channel 1
Firmware update							
Interface							
E-mail server							
PDF report							
Loggers alerts							
Loggers group							

5.1.3 Configure the period of measure – Time Period

For each logger that you have:	Logger LOG0014E5 settings	×
	Device identification RF Settings	Time Period Thresholds
Click on Time Period	Firmware mode :	
	Mode :	Uve / record mode Monitoring mode
 → Select Normal to give a value in hours and/or in minutes → Select Fast to give a value in second lower than 1 	Options :	Leds Oversampling Buffer restudion 255 0 : pas de debuffer isation 255 : tout debufferiser d'un coup
minute	Period settings	
Click on Save	Période Monitoring :	Promet
		SAVE CANCEL

5.1.4 Configure the thresholds





5.2 Configure your COL

Each time you save a new configuration for the COL, do not forget to :

- Press ACK Button on the back of your COL If you are not able to reach the COL, wait for 2 minutes
- After the sound BEEP, refresh the internet page (click F5)

5.2.1 Configure the Identification

Click on Devices identification	Logger COL00005C settings	×
	Device identification RF Settings	Collector settings
➔ You can change the device ID (ex: 1, 2)	Serial Number:	COLO0005C
➔ You can change the Devices description (ex: roof)	Device ID:	92
Click on Save	Device Description:	C01.22-2,00005C
	Product type:	COL22-2
	Firmware version:	4.0.2
		SAVE CANCEL

5.2.2 Configure the channel – RF settings

You powered your COL and your logger(s) by default on the channel 1 which is the channel for startup. Once you have change the channel of all your loggers, you must change the channel of your COL:

• Use the **same configuration** (channel and securization) as the one use for **your loggers** because the loggers and the COL must have the **same channel** to communicate

	Logger LOG000CBA settings		×
Click on RF Settings		Time Period Thresholds	
➔ Select the same working channel as the one use for your loggers	RF channel	 Europe 868 Mile: 915 Mile: 	
➔ Activate the security if you did it for the loggers – use the same securization as the one used for your loggers	Boot channel: Working channel:		
Click on Save	Power consumption Output power:	Jodim 30mA - Optiack k +Jodim	
	Sensitivity:	High Low Default is High	
	Channel securization		
	Security:	Adve COLDODDSC	
		SAVE	CANCEL
	Drewstee Alers	tessages ⁴ Help	
• Press ACK Button on the back of your COL	Dashboard Display	vrds per page	
• After the sound BEEP, refresh the internet page (click F5)	Alert Log Config- Reports Sectings Device Firmene spote	Setted Number Description D Logger type Mail COLDOLOG 1 **** 2000001000 ***** ******	-
The new working channel of the COL is now displayed with the securization symbol (if used)	Interface E-mail server POP report Loggers sens Loggers group	MEDINATE 😭 TAKAS DAS.	

- Pass the magnet on your loggers
- After the sound BEEP, refresh the internet page (click F5)

The new working channel of the loggers are now displayed with the securization symbol (if used) <u>Remark:</u> You can now return to **5.1.3 Configure the period of measure – Time Period** to end the configuration of your loggers

5.2.3 Collector settings

# Dashboard	Display 10	records per	page				
Alert Log		Config.	Serlal Number	Description	D	Logger type	RF settings
Reports							
C Settings			COL00005C	roof	1	COL22-2	Channel 7
			L0G001513	your description	5395	L0622-2	Channel 7
Firmware update							
Interface							
E-mail server							
PDF report							
Loggers alerts							
Loggers group			and a second sec	COMMAND LIST			
Loggers group	RELO	AD BE HEER	MATE TERASE DATA				

Click on Collector Settings	Logger COL00005C settings	
Ť	Device identification RF Settings	Collector settings
COLLECTED MEASURED	Collected measures	
The transmission frequency is the frequence of transmission	Transmission frequency:	1 Minutes +
of the collected data (by the collector) to the database - We		
recommand not to change this value	Send emails in case of alert	
0	Thresholds	Never
SEND EMAILS IN CASE OF ALERT		Only the first S Alerts
You can define here the frequence of the alert that you need		Every alert
for the emails.(for all the alerts (not recommended) only for	Options :	
the first x alerts, if you need a email when the alert is ended,		Back to normal state
		Alarm bell Transmission lost after 0 periods without any measure (0 = no alarm)
		Start elarms after 0 elarms
You can activate the alarm when there is a lost of transmission		
between the COL and the loggers (3 periods without measures		SAVE CANCEL
recommended in this case)		SAVE UNICE
Click on Save		
If you are hosting your data by your own, you will need to	Server configuration	
modify the Server configuration and the Database	Adress	www.newsteo-webmonitor.com
configuration later.	Port	
	POIL	447
If you have chosen to use the Newsteo data hosting, don't	Database configuration	
-	Database configuration	COLDODESC
-		COLODODSC
-	Name Identifier	COLODORSC
	Name	COLODODSC
	Name Identifier	COLODORSC
	Name Identifier Password	C0L00005C
	Name Identifier Password Network IP address	COLODORSC
-	Name Identifier Password Network	C0L00005C
	Name Identifier Password Network IP address	COLODOSC COLODOSC
	Name Identifier Password Network IP address Address	COLGODOSC COLGODOSC
	Name Lidentifier Password Network IP address Address Subnet mask Gateway	COLD0005C COLD005C COLD05C COLD05C COLD05C COLD05C COLD05C COLD05C COLD05C COLD05C COLD
	Name Identifier Password Network IP address Address Subnet mask	COLGODOSC COLGODOSC
	Name Lidentifier Password Network IP address Address Subnet mask Gateway	COLD0005C COLD005C COLD05C COLD05C COLD05C COLD05C COLD05C COLD05C COLD05C COLD05C COLD
-	Name Identifier Password Network IP address Address Subnet mask Gateway Dns1	COLO0005C COLO005C COLO05C
	Name Identifier Rassword Network IP address Address Subnet mask Cateway Dns1 Dns2	COLO0005C COLO0005C COLO0005C COLO0005C COLO0005C COLO0005C COLO0005C COLO005C COLO05C COLO005C COLO05C COL
-	Name Identifier Rassword Network IP address Address Subnet mask Cateway Dns1 Dns2	COLO0005C COLO005C COLO05C
If you have chosen to use the Newsteo data hosting, don't change the parameters	Name Identifier Ressword Network IP address Address Subnet mask Cateway Drs1 Drs2 Proxy	COLGODOSC COLGODOSC COLGODOSC



5.2.4 Configure your email alert

Click on Settings Click on E-mail Server				
Configure the server to receive your e-mail alerts Ask for your network administrator for this configuration. Click on Save	Constant of the second of the	A tension Messages Metry Metry Messages Metry Metry Service Se	reverses astietatur@genet.com	Gr. Cleet Gr. cleetgrpston
Click on Test Settings Verify in e-mail box that you received the e-mail of test			HELP	T SETTINGS
Click on Settings Click on Loggers alerts Click on Add an e-mail Enter the e-mail of the person who will receive the alerts Click on OK Click on Test the e-mail address Verify in their e-mail box that they received the e- mail of test	Constant of the second of the	Alers	Anistic day Displayed day (Consult / Basis Consult / Basis	X CN CACL

6 Install DB Monitor and connect DB Monitor to your own Database

If you were using the RF Monitor software before this installation, refer directly to paragraph 2

6.1 Install DB Monitor (Newsteo Kit)

Insert the USB Newsteo key Double click on : NewsteoKit_vx.x.x_aaaammjj_setup.exe Or download Newsteokit_vx.xx.x_yyymmdd_setup.zip from: http://support.newsteo.com/customer/en/portal/articles/1133777-rf- monitorinstallationmise-%C3%A0-jourlogiciel	helpme_files helpme.html NewsteoKit_v7.13.3_20160212_setup.exe
Select the Language Click OK	Installer Language Please select a language. English CK Cancel
Click Next	Newstee Kit (v1.228_20131220) Setup Newstee Kit (v1.228_20131210) Setup Wizard Newstee Kit (v1.228_20131210) Setup Wizard Newstee Kit (v1.228_20131210) Newstee Kit (v1.228_20131210)
Click I Agree	Newstee Kit (v7.12.8_d013120) Setup Constant (v7.12.8_d013120) Setup Constant (v7.12.8_d013120) Constant (v
Click Next	Newsteo Kit (v7.12.8_20131220) Setup Coose Components Coose which features of Newsteo Kit (v7.12.8_20131210) you wait to instal. Check the components you want to install and uncheck the components you don't want to install. Click text to continue. Select the topoton components you wint to install Coose which and uncheck the components you don't want to install Coose which features of Newsteo Kit (v7.12.8_20131210) you install. Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose which features of Newsteo Kit (v7.12.8_20131210) you install Coose Kit (v7.12.8_20131210) you install Space required: 29.8MB Position you mouse over a component to see Kit description. Keters Coose Kit (v7.12.8_20131210) Keters Coose Kit (v7.12.8_20131210) Coose Kit (v7.12.8_20131210) Keters Coose Kit (v7.12.8_20131210) Coose Kit (v7.12.8_20131210) Keters Coose



Click Install	Newsteo Kit (v7.12.8_20131210) Setup
	Choose Install Location Choose the folder in which to install Newstee Kit (7.12.8.20131210).
	Setup will install Newstero Kit (v7.12.8_2013/210) in the following folder. To install in a different folder, cick forwas and relect another folder. Cick Install to start the installation.
	Grief en rinder y dat d'orige and select and religions . Cat and an original the rinderson.
	Destination Folder SiProgram Files (080) [Heinsted Browse
	Space required: 29.8MB
	Space available: 30.668 Nullsoft Install System v2.33
	< Back Cancel
Click OK	Ĵ Newsteo Kit (v7.12.8_20131210) Setup □ @ 🖾
	Please wait while Newsteo Kit (v7.12.8_20131210) is being Please wait while Newsteo Kit (v7.12.8_20131210) is being
	Output folder: C:\Program Files (x86)\Newsteo\RFtoUS8Key\phivers
	Extract: slaby D Newsteo Kit (v7.12.8_20131210) Setup
	Extract: WdfC Extract: slabe Extract: slabe This operation might take several minutes
	Output folder: Extract: Widfo
	Extract: slabe Extract: slabe Output folder: Cl Program Files (x86) (Newstee (RPFoL)SBKer (privers
	Nullsoft Install System v2:33
	< Back Next > Cancel
Click Next	CP210x USB to UART Bridge Driver Installer
	Welcome to the CP210x USB to UART Bridge Driver Installer
	This wizard will help you install the drivers for your CP210x USB to UART Bridge device.
	To continue, click Next.
	< Back Next >>> Cancel
Select I accept this agreement	CP210x USB to UART Bridge Driver Installer License Agreement
	License Agreement
Select I accept this agreement Click Next	License Agreement To continue, access the following loanse agreement. To read the entire agreement, use the social bar or press the Page Down key.
	Lucanse Agreement To continue, societ the following loanse agreement. To read the entire agreement, use the social bar or press the Page Down Key. END-USER LUCENSE AGREEMENT MMORTANT. READ CAREFULLY BERORE AGREEMENT TO THIS ENDUCTION THE USE OF WHICH IS SUBJECT TO THIS ENDUCERT, THE USE OF WHICH IS SUBJECT TO THIS ENDUSER LUCENSE AGREEMENT INDICATING YOUR
	License Agreement To continue, accede the following loanse agreement. To read the entire agreement, use the accel bar or press the Page Down key. END-USER LICENSE AGREEMENT MORTATIN: READ CAREFULLY BEFORE AGREEMENT TO TERMS THIS PROVIDED. THE AGREEMENT CLICENSE DATE PROVIDED. THE AGREEMENT INDICATING YOUR CLICENSE DROUCTD. THE USE OF WHICH IS SUBJECT TO THIS END-USER LICENSE AGREEMENT. INDICATING YOUR
	Locate Agreement
Click Next	Locande Agreement
	Lucance Agreement
Click Next	Locance Agreement Society To continue, accept the following locance agreement. To read the entities agreement, use the score barr or press the Page Down key. NU-VISER LICENESS AGREEMENT MOOTHANT READ CARPENLIN'S END VISER LICENESS AGREEMENT INFORMATION IN THE PAGE CARPENLING THE THEOD PARTY PROVINCE TARY MATERIAL, OUT OF THE DATA PARTY PROVINCE TARY PROVINCE TARY MATERIAL, OUT OF THE DATA PARTY PROVINCE TARY PROVINCE TARY MATERIAL, OUT OF THE DATA PARTY PROVINCE TARY PROVINCE TAR
Click Next	Lucance Agreement
Click Next	Locance Agreement Source Image: Contrainer, accept the following locance agreement. To read the stress and provide the social bair or posets the Page Down key. Image: Contrainer, accept the following locance agreement. To read the stress and provide the social bair or posets the Page Down key. Image: Contrainer, accept the following locance agreement. To read the stress and provide the social bair or posets the Page Down key. Image: Contrainer, accept the following locance agreement is used to the contrainer social bair of the agreement is locance the social bair or posets agreement is locance the agreement is locance the social bair or posets agreement is locance the agreement is locance the social bair or posets agreement is locance the social bair or posets agreement is locance the agreement is locance the social bair or posets agreement is locance the social bair or posets agreement is locance. Contrainer
Click Next	Cleance Agreement Second Second To ordina, societ the following loance agreement. To read the effect Second Second
Click Next	Locance Agreement Source Image: Contrainer, accept the following locance agreement. To read the stress and provide the social barring locance agreement. To read the stress and provide the social barring locance agreement. To read the stress and provide the social barring locance agreement. To read the stress and the social barring locance agreement is used to other the agreement is located the agreement agreement agreement agreement is located the agreement agre
Click Next	Closene Agreement Continue, accept the following losene agreement. To read the error accept the following losene agreement. To read the error accept the store bar or sens the Page Down Key. Not VISTE AGREEMENT TO TERMS Image Down Key. Image Down Key. Image Down Key.
Click Next Click Finish	
Click Next	<complex-block></complex-block>
Click Next Click Finish	Loanae Agreement Image: Control Agreement
Click Next Click Finish	<form></form>
Click Next Click Finish	<complex-block></complex-block>

6.2 Connect DB Monitor to your own Database

After the restart of your computer, Right click on the DB Monitor icon Click on Run as administrator	Open Troubleshoot compatibility Open file location Run as administrator Pin to Taskbar Pin to Start Menu
Select the Language	DBMonitor : Configuration wizard
Click Next	Helle, Welcome in configuration assistant for <u>RewSTEO DBMonitor software</u> 1. General Optione 2. Database 3. Finalization Application settings Language Lan
	de < Back 🖉 Anton 🗶 Frish
Remember the name, the password and the IP adress of the Database	DBMonitor : Configuration wizard
which has been created in paragraph 3.2.2 Create your Database	Hello, Welcome in configuration assistant for NEWSTEO DBMonitor software
Calast Devesta Database	1. General Options O local database
Select Remote Database	2. Dutabase C:\Users\Public\Documents\NE\WSTE0\RFMonitor\RFD.atabase\RFD.ata.bin
Fill the Username and the Database name with the Name	3. Finalization Recent files :
Fill the Password with PassWord	Remote database :
Fill Hostname with the IP adress	Database type : MySQL +
	Database connection settings Hostname: 192.168.0.80
Click Check Connection	HTTP Encapsulation :
	Port: 3306
	Username: COL000001 Password :
You get the message "Database connection test succeed"	Password :
	Database name: COL000001
Click OK	Check connection Geck connection
	1 Database connection test succeed
Click Next	
Click Validate	DBMonitor : Configuration wizard
	Hello, Welcome in configuration assistant for NEWSTEO DBMonitor software 1. General Options 2. Database 3. Finalization Click on Validate button to set parametes. Otherwise, click Back button.



DBMonitor : Confi Click Finish 8 Hello, Welcome in configuration assistant for NEWSTEO DBMonitor software4 tor software (version 7.8.2.0) 2. Database Click or Validate button to set parameters 3. Finalizatio , click Back button Validate (# < Back | => Next > Kinish You are now connected to your empty Database (P D File Measures view measures and charts CR Logs Views logs : devices alerts, pc events and i Application settings, database connection ression date : 2013/12/24 16:04:50 Imp Records: 0 · 0 Page: 1/1 100 00 00

7 Connect the COL to your own database

Click on Settings	Descripting Ann Pressper Descripting Descript	
Click on Devices	A Aint Log Config. Solution Towards for page 1 House w	
Click on the Configuration icon on the line of your COL	Reven	
Click on Collector Settings	Processor Theoderation Low Monitoria Description Description Evaluation Description Description Objects ratio Using strate Description	
	dige matrice and international	
Remember the name, the password and the IP adress of the		
Database which has been created in paragraph 3.2.2 Create	Server configuration	
your Database	Adress 192168.0.80	ļ
In the part SERVER CONFIGURATION:	Port 80	
Fill the Name and the Identifier with the Name		
	Database configuration	
Fill the Password with PassWord	Name	
Fill the Address with the IP adress	Name COL000001	
Click on Save	Identifier COL000001	
Press ACK Button on the back of your COL - If you are not able to reach the COL, wait for 2 minutes	Password	
After the sound BEEP, refresh the internet page (click F5)	SAVE	CANCEL
	Xillonity US21	
Click on Refresh in the DB Monitor software	Name Oracle 7 Oracle 7 <th< th=""><th>d liter : Nore : [2013/12/24 1] [2013/12/24 24 16:54:18</th></th<>	d liter : Nore : [2013/12/24 1] [2013/12/24 24 16:54:18
You can now visualise your data on your own Data base	2 And	57.00 55.40 53.80
	11.2	32.20
	15 Topic description Temperature Topic description Deta Deep	49.00
	vour destroppon 1 tempfd/sture vour destroppon Detta Desn/ vour destroppon Detta vour destroppon 1 tempfd/sture vour destroppon 1 tempfd/sture vour destroppon 1 tempfd/sture	
	dy	

If you can't remember the IP address of your computer: Click WINDOWS icon Enter the command: cmd.exe Press Enter	Programs (1) Cond.exe See more results Cond.exe Shut down
 Write ipconfig Press Enter 	C:\Windows\system32\cmd.exe Microsoft Windows [Version 6.1.7601] Copyright (c> 2009 Microsoft Corporation. All rig C:\Users\QA>ipconfig_
 Get your IP address on the line IPv4 Address Click [X] to close the windows 	C.Windowstystem32(cmd.exe Hicrosoft Windows: Usersion 6.1.7681] Copyright (c) 2009 Microsoft Corporation. All rights reserved. C:\Users\QA})ipconfig Windows IP Configuration Ethernet adapter Connexion au réseau local: Connection-specific DMS Suffix .: Link-local IPv6 Address: PIPv4 Address: Bunnet fask

Address of the manufacturer:

NEWSTEO S.A.S. 93 avenue des Sorbiers – ZE Athelia 4 13 600 La Ciotat – France