



1 Test the devices

And your settings before installing the devices on site

(2) Vertical antennas

Radio antennas must be upright

(3) Antennas at more than 30cm

For a better radio transmission, place antennas more than 30cm away from a wall or another Newsteo antenna.

4 Logger and key on the same channel

The data loggers and the radio key must be on the same radio channel to communicate.

5 Do not use channel 1 Change to another channel.

(6) Monitoring mode

Use the "MONITORING" mode
(except for specific conditions, watch video or check user quide)

7 Test the radio range

From your data loggers with RF Monitor before final positioning.
(watch video or check the radio transmission guide)

(8) Battery saving

Choose a measurement period> 1 min

9 Battery saving

Put the data loggers in Hibernate mode when they are not in use

10 Change the battery under 30%

When the Newsteo radio data loggers are launched for the first time, the battery level may be medium or low. After the normal period of chemical break-in, the level of the battery rises. In use, when the level goes below 30%, change the battery